



ASSEMBLY INSTRUCTION



ІНСТРУКЦІЯ А1568PL-1CL

| | | |
|---------------------------------|-----------|------------------------|
| <p>1 OFF</p> <p>01</p> | <p>02</p> | <p>03</p> |
| <p>04</p> | <p>05</p> | <p>06</p> |
| <p>N L</p> <p>5mm</p> <p>07</p> | <p>08</p> | <p>14 ON</p> <p>09</p> |