


ASSEMBLY INSTRUCTION

## ИНСТРУКЦИЯ А1660PL-8АВ

A



Mode	Accessories View	Quantity
А		16
В	<i>`</i> ®®⊕⊕®®	16
С		16
D	-+**	16
E	<del>~~~~~</del>	16
F		16
G		16
Н		16
I		16
J	<del>&amp; &amp; &amp; &amp; &amp; &amp;</del>	16
К	<del>~~~~~~~~~</del>	16
L	<del>~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~</del>	12
Ν	<del>~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~</del>	6
М	<del>~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~</del>	1